



General Installation Notes

Attention: This information is not a construction document and is for planning/design purposes only

Butyl tape:

Butyl Tape for Air tightness must be installed at temperature above 42 degrees, the higher, the better.

Frame Installation:

Frame must be installed true, square, and plumb in all directions to w/in 1mm/meter

Attention: Wood is natural material, only the best materials are used but it is possible that the frame will not be true straight. At such an occasion the installation must adjust accordingly through the placement of the screws.

Attachment:

The frame is either installed with screws (operable sash) or brackets (fixed sash)

Additional Information:

See video and project specific detail drawings:





Inside Finish:

The inside can be installed to max 1/2" on all three non-hinge sides and 1" on the hinge side. Should this be not sufficient then a wider frame can be ordered.

Outside Finish:

The outside finish can be installed to 1/8" of the frame edge. Using this space for additional insulation ("over-insulation" of the frame) is useful for window insulation performance.

Finished outside opening





General Installation Notes

Attention: This information is not a construction document and is for planning/design purposes only

Butyl tape:

Butyl Tape for Air tightness must be installed at temperature above 42 degrees, the higher, the better.

Frame Installation:

Frame must be installed true, square, and plumb in all directions to w/in 1mm/meter

Attention: Wood is natural material, only the best materials are used but it is possible that the frame will not be true strait. At such an occasion the installation must adjust accordingly through the placement of the screws.

Attachment:

The frame is either installed with screws (operable sash) or brackets (fixed sash)

Additional Information:

See video and project specific detail drawings:



Inside Finish:

The inside can be installed to max 3/4" on all three non-track sides and 1/4" on the track side. Should this be not sufficient then a wider frame can be ordered.

Outside Finish:

The outside finish can be installed to 1/4" of the frame edge. Using this space for additional insulation ("over-insulation" of the frame) is useful for window insulation performance.

